




- 1 Battery (12 V)
- 2 High-voltage battery
- 3 High-voltage disconnect device




Airbag



Gas generator




Seat belt tensioner



Restraint systems control unit



Gas-filled strut



Body reinforcement



Battery 12 V



High-voltage battery



High-voltage components



High-voltage disconnect device



High-voltage disconnect device


The high-voltage disconnect device is located under the lid of the fuse and relay box on the rear panel in the trunk.

Open lid (1) / Pull out switch (2) on fuse and relay box (3)



Door hinges

The SLS AMG is equipped with a safety system which uncouples the door hinges from the hinge arms when the vehicle comes to rest lying on its roof after an accident. Each door hinge (1) contains a pyrotechnic initiator (2) which is triggered by the restraint systems control unit. When the door lock is opened, the doors can be pulled off the hinge arms (3).



Vehicle identification

HV charge socket



Right fender



Left fender

