






Mercedes-Benz

E-Class HYBRID PLUS Wagon model 213 as of 2017




- 1 12 V Battery, Left-hand drive
- 2 12 V Battery, Right-hand drive
- 3 High-voltage battery
- 4 HV charge socket
- 5 High-voltage disconnect device
- 6 Alternative high-voltage disconnect device, Left-hand drive
- 7 Alternative high-voltage disconnect device, Right-hand drive


Note

The alternative high-voltage disconnect device is only to be operated when the high-voltage disconnect device in the engine compartment is inaccessible.


Switch off the ignition before operating the high-voltage disconnect device and the alternative high-voltage disconnect device.




Airbag




Gas generator



Seat belt tensioner




Restraint systems control unit




Gas-filled strut



Pedestrian protection



Fuel tank



12 V Battery



High-voltage battery




High-voltage components



High-voltage disconnect device




Alternative high-voltage disconnect device



High-voltage disconnect device

The high-voltage disconnect device is located in the engine compartment next to the coolant expansion reservoir on the right (viewed in the direction of travel).



High-voltage disconnect device in engine compartment

Operate release (1) / Pull out switch (2)

Alternative high-voltage disconnect device

The alternative high-voltage disconnect device is located under the cover of the fuse box on the left of the cockpit. It is marked with an information label.



Information label on alternative high voltage disconnect device




Remove cover (1) of fuse box / Cut line at marked location (2)




Mercedes-Benz

E-Class HYBRID PLUS
Wagon model 213
as of 2017



Vehicle identification



HV charge socket



Left of trunk lid